



How to setup Repotec Router [Dynamic Configuration]




- Login into the router with **192.168.16.1** .
- The User name: **admin** .
- The Password : **admin** .




- Click **Quick Start** and then select: **Run Wizard** .




- And Click **Next**.




- Type the **New Password** and **Confirmed Password: tedata**.
- And Click **Next**.




- And then Chose **Cairo** from **Time Zone**.
- And Click **Next**.



- And then Chose **PPPoE/PPPoA**.
- And Click **Next**.



- Type the **Username** and **Password** as **Show above**.
- And then **VPI: 0 VCI: 35**.
- And then **Encapsulation: PPPoE LLC**.
- And Click **Next**.



- And Click **Next** to finish the configuration.



:: Copyright © 2007 . TE Data Support Team . All Rights Reserved ::

:: For Further Informations Call Us At 19777 ::

